www.bergtoys.com

User manual

Gebrauchsanweisung

Gebruikershandleiding

Mode d'emploia

Manual de usuario

Manual de utilizador



GranTour

BERG
www.bergtoys.com

GranTour




BERG
www.bergtoys.com
GranTour
M10x16 1x
M10 1x
M8x16 4x
M8 4x
NYLON 2x
M8x16 4x
M8 4x
M10x16 1x
M10 1x
M12x55 2x
M12 4x
M12 2x
!
2x

www.bergtoys.com

GranTour

ENGLISH EN

DEUTSCH D

NEDERLANDS NL

FRANCAIS F

ESPAÑOL ES

PORTUGUÉS PT

EN

Introduction

Congratulations on the purchase of your BERG Toys product!

BERG Toys does everything to ensure that the product we design and produce are robust and safe. BERG Toys products last for a long time, but from time to time they need a little maintenance. You'll find the maintenance instructions in this User's Manual. If you follow these instructions, you can be sure of years of use from your very robust toy.

And visit our Home page on www.bergtoys.com where you can read more about BERG Toys and view photos of the products. You can naturally also report your experience of BERG Toys and our products. You can send your comments to info@bergtoys.com. We warmly invite you to send BERG Toys an e-mail with your suggestions for improvements and other experiences.

Contents

Instructions for use

1. Safety
    - 1.1 Brakes
    - 1.2 Tyre pressure
    - 1.3 Steering
    - 1.4 Trailer
    - 1.5 Seat belts
2. Rules for use

Maintenance

3. Maintenance programme
4. Maintenance operations
    - 4.1 Frame
    - 4.2 Wheels / Tyres
    - 4.3 Steering
    - 4.4 Chain
    - 4.5 Cranks
    - 4.6 Freewheel
    - 4.7 Plastic components

Garantie

5. Guarantee period
6. Guarantee conditions
7. To be completed
8. Spare parts

Instructions for use

1. Safety

The GranTour is not classified as bicycle. This means that they are not allowed on public roads. They all carry the TÜV / GS quality mark. Children (under 12 years) should only ride on the GranTour under adult supervision.

1.1 Brakes

The GranTour has a hand brake. Braking is carried out by pulling up the brake lever between the seats (1). This hand brake operates on the rear wheels. The parking brake is set by lifting the brake lever and placing the metal blocking strip beneath it. Always put on the parking brake when the GranTour is stationary (2).





1.2 Tyre pressure

Before use, check that the tyre pressure meets safety standards (minimum 2.0 bar and maximum 2.2 bar). The operation of the brakes and steering depend on this.

1.3 Steering

Check that the steering is working smoothly. If not, you should first rectify this. Directions for doing so are given in the Maintenance section.

1.4 Wagon

If there is a Wagon attached to the GranTour, remember that this will increase the braking distance. Do not use the Wagon with the GranTour on hills with a gradient greater than 5%.

EN

1.5 Seat belts



2. Rules for use

- Before you use your BERG Toys product, check that everything is working properly.
- Children should only use the GranTour under supervision.
- The GranTour must not be used on the public road. Drive at the appropriate speed, depending on the situation. If you ride on the slope of a hill, there is a risk of tilting. Downhill, you can achieve quite high speeds. Remember that this will make your braking distance longer!
- Do not turn sharply at high speeds, because this carries the risk of overturning.
- Also, pay attention to your surroundings.
- Do not reverse at high speed. This can lead to loss of steering control.
- The front wheels may leave the ground if you brake while reversing at speed.
- Do not drive when under the influence of alcohol or medicines that can affect your powers of observation or your reactions.
- Bumping or other stunts increase the chance of injuring yourself and damaging the products. BERG Toys can accept no liability for injuring and damaged so caused.
- The GranTour should always be braked using the hand brake. This works on the two rear wheels.
- Place no unnecessary objects on or over the brake lever or the steering wheel. Make sure that the brakes and steering can always operate properly.
- Clothing and upper limbs can become trapped between moving or hinged parts.
- Avoid trailing clothing, such as scarves and laces. These can get caught in moving parts, which can cause accidents.
- Avoid contact with the wheels when driving.
- The driver or owner is responsible for assessing whether the product is the right size for him / her.
- Always ensure that the driving seat is in the correct position in relation to the pedal, so

that you can drive safely.

- Do not get on or off while in motion.
- Do not overload the vehicle.
- Do not drive in the dark without lighting.
- When the protective covers are removed for maintenance, always replace in the original position before use.
- When parking, always use the parking brake.
- Read the instructions on the guarantee certificate carefully.

Maintenance

EN

3. Maintenance programme

Some maintenance is required to use the product safely and to prolong your enjoyment. This chapter describes how often maintenance operations are required. There is then a short description of how to carry out the maintenance work required.

Daily:

- Check tyres for damages and replace them if necessary.
- Check tyre pressure and adjust if necessary (between 2.0 and 2.2 bar).

Monthly

- Clean frame and maintain it when required.
- Check nut and bolt connections and if necessary tighten.
- Check frame for breakage.
- Check chain tension and adjust if necessary.
- Clean and oil chains.
- Check steering for damage and replace if necessary.
- Lubricating:



Annually:

- Clean plastic components and check for damage; replace if necessary.

4. Maintenance operations

4.1 Frame

The frame is powder coated. This provides a hard layer of paint. To prevent rusting, it is important to clean the frame regularly. If you want to protect the frame with grease, only use acid-free Vaseline. Small area's of damage can be touched up with paint. The appropriate paint can be bought from your dealer.

4.2 Wheels / Tyres

The wheels are fitted with ball bearings. Check the tyres and rims for damage regularly (splits,

cuts, cracks and bulges). Watch out: damage to tyres and rims can cause accidents! Tyre pressure should be at least 2.0 bar with a maximum of 2.2 bar (remember that pressure increases with high temperatures). If the tyres are at the correct pressure, the vehicle will run easily and smoothly. At too low a pressure, the tyres will puncture faster and there will be excessive wear and tear.When the tyre pressure is too high, the tyre may pop of the rim. This can lead to dangerous situations. (Watch out -pressure rises in bright sun and high temperatures!) Tyres should not come into contact with oil, grease and fuel. Make sure that the valve caps are always fitted to the valves.

4.3 Steering

The steering mechanism should be regularly oiled in order to operate smoothly. The steering mechanism should be checked monthly for the following:

- Breakage, wear and tear and / or damage to all components of the steering mechanism.
- Tightness of screws.

4.4 Chains

The chains need greasing regularly to run smoothly.If the chains are too tight the vehicle will be hard to pedal, and there is a high chance that the axles will break. If the chains are not tight enough, however, they can easily come off the sprockets, and damage can be caused to the chain guard. The chains are tensioned as described below. To tension the chains:

- Loosen off screw A and nut B.
- Tighten the chain using nut C.



Watch out: Do not pull it too tight! By pushing the chain down firmly with your thumb you should be able to move it 3 cm or so. Remove the chain guard to check this. Retighten A,B and C.

4.5 Adjusting the cranks when running in a new GranTour

After using the GranTour (a few days of intensive use up to two weeks normal use), the bolts fastening left and right-hand cranks should be tightened up. Note: this needs to be 'hand tight', i.e. with a maximum torque of 30 Nm. You can also contact your dealer. He will be happy to do this for you. (It is normal for the crank fittings to bed in after a short period in use as a result of the forces on the pedals. An additional effect of this is that some play can develop, which could result in some damage to the crank and the spindle. This play can be eliminated by tightening the bolts further).



4.6 Freewheel

An Automatic Freewheel (AF) is mounted on the driver side. The automatic freewheel causes the pedals to stop when you do not move your feet. The automatic freewheel also allows you to drive in reverse.

A Freewheel (F) is mounted on the passenger side. With this Freewheel you can only drive forwards. The Freewheel requires no maintenance.

4.7 Plastic parts

The plastic components must be regularly checked for damage and breakages. In the event of breakages you should replace the component in question immediately with an original part, to ensure the safety of the user.

Guarantee

5. Guarantee period

The owner of this product from BERG Toys B.V. has the following warranty on the product:

- One year from the purchase docket on the product.
- On the whole, no warranty is provided on parts that are subject to wear (such as chain and tyres).

6. Guarantee conditions

The owner can only make a claim under the guarantee by submitting the original purchase note together with the original guarantee certificate to BERG Toys B.V. or the dealer from whom the product was purchased.

The guarantee applies exclusively to faults in the materials and construction of the product or its components.

The guarantee is invalidated if:

- The product is incorrectly and/or carelessly used, or used in a way that is not in accordance with its purpose.
- The product is not assembled and maintained in accordance with the instruction manual.
- Technical repairs to this product have not been carried out in a nonprofessional
- manner.
- Components subsequently fitted do not comply with the technical specifications of the product, or are incorrectly assembled.
- Damage, such as rust or normal wear to the paint, occurs as a result of climatic conditions.

The liability of BERG Toys B.V. is expressly excluded in respect of damage to (parts of) the product as a result of:

- Faulty adjustment/tension of the steering wheel, steering mechanisms, chains, tyres and gear hubs.
- Failure to replace parts such as chains and tyres at the appropriate time.

During the guarantee period, all material or construction faults reports to BERG Toys B.V. will be either repaired or replaced by BERG Toys B.V. at the company's choice.The owner of this product can only make a claim under this guarantee by taking the product to a BERG Toys dealer for inspection. At the same time, the original guarantee certificate (completed and with the dealer's stamp) and the original purchase note must be given to the dealer. If the owner has moved house, or the dealer is no longer available, BERG Toys B.V., will assign the warranty to the nearest BERG Toys dealer, if requested.

If the application under the guarantee is not valid, all costs will be born by the owner.

The guarantee certificate may not be transferred to third parties.

EN

7. To be completed

So that you always have the details of your BERG Toys product to hand, please enter the following data. The serial number can be found on the silver sticker on the underside of the frame of the product.

Name des Händlers:	Händlerstempel:
Addresse:	
Wohnort:	
Tel. nr.:	
Productnummer:	
Serienumber:	
Kaufdatum:	

BERG Toys B.V.
www.bergtoys.com
info@bergtoys.com

8. To obtain spare parts

To obtain spare parts, contact your BERG Toys dealer, or visit the website www.bergtoys.info. Subsequently fitted components that do not comply with the technical specifications for the product or which are incorrectly assembled can invalidate the guarantee.